

DSM2 Learning Series: Planning Studies

Session 1: DSM2 Input Hands-on Exercises

October 27, 2023



DISCLAIMER

All DSM2 and CalSim simulations
in this training are

**EXAMPLES AND SHOULD ONLY BE
USED FOR TRAINING**

Reminders

1. Raise your hand (on Teams) when you complete each step
2. If you have a question, enter it into the Teams chat, even if you are in the room

DSM2 Learning Series: **Planning**


Skills Learned

- **Session 1: DSM2 Planning study setup**
- Session 1 Hands-On Exercises:
 - Plotting DSM2 input with Jupyter notebooks
 - Running DSM2 planning studies
- Session 2: Plotting DSM2 output with Jupyter notebooks

Topics Not Covered

How to



- Run CalSim
- Change channel geometry
- Add/remove/change structures



DSM2 Learning Series


DSM2 grid map

<https://data.cnra.ca.gov/dataset/dsm2-georeferenced-model-grid/>



CalSim -> DSM2



CalSim,
Delta p
ortion



Delta Cross
Channel

Mokelumne River
inflow

Calaveras River
inflow



DSM2
Delta
grid

Folders* in the CalSim/DSM2 Planning setup

Folder	Description
calsim_output	CalSim output
delta	DSM2 planning studies

***Red** means we will not change anything in the folder

***Green** means we will change something in the folder

Folders* in the CalSim/DSM2 Planning setup

The *Delta* folder

Folder	Description
calsim_output	CalSim output
Delta/DSM2_v822plan/	DSM2 planning studies
bin/	DSM2 executables
common_input/	Shared DSM2 inputs
postp/	Jupyter notebooks for plotting input/output
pydelmod_plan/	conda environment for jupyter notebooks
scripts/	Post-processing scripts
studies_planning	DSM2 example planning studies
timeseries_plan/	DSS inputs shared by all studies
vista/	Vscript/Vista application

***Red** means we will not change anything in the folder

***Green** means we will change something in the folder

Folders* in the example baseline study

Folder	Description
calsim_output	CalSim output
Delta/DSM2_v822plan/	DSM2 planning studies
studies_planning/baseline/	Existing conditions study
input	Study specific fixed input
output	Study output
scripts	For creating DSM2 input from CalSim output
timeseries	Study specific time series output

***Red** means we will not change anything in the folder

***Green** means we will change something in the folder

Planning Studies

Baseline vs Alternative

Baseline Study

Existing
conditions

Alternative Study

Climate change
hydrology
(CalSim)

Sea level rise 55
cm (1.8 feet)

DSM2 Learning Series: **Planning**

Skills Learned

- Session 1: DSM2 Planning study setup
- **Session 1 Hands-On Exercises:**
 - Pre-process CalSim output for DSM2
 - Plotting DSM2 input with Jupyter notebooks
 - Running DSM2 planning studies
- Session 2: Plotting DSM2 output with Jupyter notebooks



DSM2 Learning Series

Topics Not Covered

How to

- Run CalSim
- Change channel geometry
- Add/remove/change structures


Setting up and running DSM2, plotting input

- For each scenario,
 - Create a copy of the CalSim output DSS file
 - Edit the pre-processor batch file
 - Run the pre-processor
 - Create input plots
 - Run the models
 - dsm2_batch.bat

Running the DSM2 Pre-processor

alternative scenario: copy CalSim output to DSM2 folder


- For the alternative scenario,
 - Copy the CalSim output file for the scenario into the DSM2 planning study folder



Running the DSM2 Pre-processor

baseline scenario: copy CalSim output to DSM2 folder

- For the baseline scenario,
 - Copy the CalSim output file for the scenario into the DSM2 planning study folder



Running the DSM2 Pre-processor baseline study

- For the baseline scenario (only pre-process one run at a time),
 - Run the pre-processor create DSM2 DSS input

Starting the script

Command Prompt Prepro.bat config.inp

```
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>prepro.bat config.inp
```

```
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>if {config.inp} == {} (  
echo "usage:  prepro config-file"
```

```
or: python postpro.py *.dss {pathname} {out}.dss  
read DSM2 15-MIN output file: timeseries/2021ex.dss  
postprocess pathnames:  
/DWR/RSAC054/STAGE/01DEC1920 - 01OCT2015/15MIN/HARMONIC_NGVD_20230413/  
/DWR/RSAC054/STAGE/01JAN1921 - 01SEP2015/15MIN/PLAN_DETREND_NAVD_20230413/  
/FILL+CHAN/RSAC054/EC/01JAN1921 - 01SEP2015/15MIN/PLAN_2021EX/  
all process done
```

done

```
D:\temp\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>
```

Running the DSM2 Pre-processor alternative study

- For the alternative scenario (only pre-process one run at a time),
 - Run the pre-processor create DSM2 DSS input

Starting the
script

Command Prompt - prepro.bat config.inp

```
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>prepro.bat config.inp
Prepro is needed only when the CALSIM file changes.
Extending flows
C_SAC048
_
```

```
or: python postpro.py *.dss {pathname} {out}.dss
read DSM2 15-MIN output file: timeseries/2040alt.dss
postprocess pathnames:
/DWR/RSAC054/STAGE/01DEC1920 - 01OCT2015/15MIN/HARMONIC_NGVD_20230413/
/DWR/RSAC054/STAGE/01JAN1921 - 01SEP2015/15MIN/PLAN_2040ALT/
/FILL+CHAN/RSAC054/EC/01JAN1921 - 01SEP2015/15MIN/PLAN_2040ALT/
all process done
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>
```

done

Running the DSM2 Pre-processor

Empty catalog error

```
Command Prompt

File "D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative\scripts\planning_ec_mtz_slr55.py", line 6
3, in planning_ec_mtz
    ndo=DataReference.create(findpath(CALSIM,"/CALSIM/NDO/FLOW-NDO//"+STEP+"/"
File "D:\DSM2_Planning_2023\delta\DSM2_v822plan\vista\lib\Lib\vdss.py", line 89, in findpath
    return g.find(pa)
        at vista.db.dss.DSSCatalogReader.readCatalog(DSSCatalogReader.java:95)
        at vista.db.dss.DSSCatalogReader.<init>(DSSCatalogReader.java:82)
        at vista.db.dss.DSSUtil.createCatalogReader(DSSUtil.java:562)
        at vista.db.dss.DSSGroup.getInitializedGroup(DSSGroup.java:108)
        at vista.set.GroupProxy.initializeGroup(GroupProxy.java:205)
        at vista.set.GroupProxy.getNumberOfDataReferences(GroupProxy.java:77)
        at vista.set.Group.find(Group.java:325)
        at sun.reflect.NativeMethodAccessorImpl.invoke0(Native Method)
        at sun.reflect.NativeMethodAccessorImpl.invoke(NativeMethodAccessorImpl.java:62)
        at sun.reflect.DelegatingMethodAccessorImpl.invoke(DelegatingMethodAccessorImpl.java:43)
        at java.lang.reflect.Method.invoke(Method.java:498)

java.lang.IllegalArgumentException: java.lang.IllegalArgumentException: Catalog is empty ?

usage: python postpro.py *.dss
       or: python postpro.py *.dss {pathname}
       or: python postpro.py *.dss {pathname} {out}.dss
read DSM2 15-MIN output file: timeseries/2040alt.dss
postprocess pathnames:
/DWR/RSAC054/STAGE/01SEP2010 - 01SEP2014/15MIN/PLAN_2040ALT/
all process done
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>
```

"Catalog is empty ?" error

Delete the dsc and dsd files

Clipboard

Organize

New

Open

Select

>

This PC

>

D Drive (D:)

>

DSM2_Planning_2023

>

delta

>

DSM2_v822plan

>

studies_planning

>

alternative

>

timeseries

>

CALSIM

>

>

>

>

Name

Date modified

Type

Size

calsim_2040alt.dsc

10/25/2023 5:45 PM

DSC File

1 KB

calsim_2040alt.dsd

10/25/2023 5:45 PM

DSD File

0 KB

calsim_2040alt.dss

10/12/2023 6:51 AM


DSS File

400,133 KB


Jupyter notebook for plotting model input

Notebook filename	Purpose
2021_example_bnd.ipynb	Compare DSM2 boundary inputs (flow, stage, EC) from multiple scenarios.


Plots Types created in input notebook



Daily mean bar chart, aggregated by month





Daily Mean Exceedance probability




Box and whisker

Delta Boundary Flows


Inflow




Export




Other Delta Boundaries




Monthly Mean Net Delta Outflow



SJR @ Vernalis EC Daily Mean EC



Martinez Mean Stage



Martinez Mean EC

DSM2 Learning Series: **Planning**

Skills Learned

- Session 1: DSM2 Planning study setup
- **Session 1 Hands-On Exercises:**
 - Pre-process CalSim output for DSM2
 - **Plotting DSM2 input with Jupyter notebooks**
 - Running DSM2 planning studies
- Session 2: Plotting DSM2 output with Jupyter notebooks



DSM2 Learning Series

Topics Not Covered

How to

- Run CalSim
- Change channel geometry
- Add/remove/change structures

Plotting input with Jupyter notebook

starting Jupyter notebook application


1. Use "notebook.bat" to start jupyter notebook

```
Command Prompt - notebook.bat

D:\DSM2_Planning_2023\delta\DSM2_v822plan\postp>notebook.bat

D:\DSM2_Planning_2023\delta\DSM2_v822plan\postp>set PATH=c:\Wind
```

2. Jupyter notebook opens in web browser





Plotting input with Jupyter notebook

Opening a notebook

1. Click "workshop_notebooks"

2. Open the file
2021_example_bnd.ipynb



Plotting input with Jupyter notebook

notebook configuration

1. Make sure these lines point to your study folders/files

```
▼ # Read in scenarios
dir_plan = '../..../studies_planning/'
dir2021base = dir_plan+'baseline/'
dir2040alt = dir_plan+'alternative/'

▼ scenarios = [
    {'name': 'baseline',      'fpath': dir2021base+"timeseries/2021ex"},
    {'name': 'alternative',   'fpath': dir2040alt+"timeseries/2040alt"},
]


# Add a wateryear type column
wyt_c3f2020 = dir_plan+"baseline/timeseries/CALSIM/calsim_2021ex.DSS"
df_wyt2020 = pdmu.read_calsim3_wateryear_types(wyt_c3f2020)

# period93 = ['1922-10-1', '2015-9-30']
period93 = ['2010-10-1', '2014-9-30']
```

2. Modify for 4 year time period

Plotting input with Jupyter notebook

Run all cells



Plotting input with Jupyter notebook


Changing variable type or station on Jupyter notebook plot

Select station

Select variable

```
In [69]: options = {'yaxis_name': 'Monthly Mean Flow (cfs)', 'title': 'Flow Monthly Mean Timelines'}  
pdmn.plot_step_w_variable_station_filters(df_flow, df_stations, options)
```

executed in 668ms, finished 10:20:10 2023-09-25



Variable **FLOW** Station **SAC Freeport**

Show Data

Save data

Export Plots

Plot prefix: plot

DSM2 Learning Series: **Planning**

Skills Learned

- Session 1: DSM2 Planning study setup
- **Session 1 Hands-On Exercises:**
 - Pre-process CalSim output for DSM2
 - Plotting DSM2 input with Jupyter notebooks
 - **Running DSM2 planning studies**
- Session 2: Plotting DSM2 output with Jupyter notebooks



DSM2 Learning Series


Topics Not Covered

How to

- Run CalSim
- Change channel geometry
- Add/remove/change structures

Setting up and running DSM2

baseline study: change starting and ending dates



1. open the config.inp file


2. Comment/uncomment
START_DATE, QUAL_START_DATE,
END_DATE to create a four year run, 2010-2014

```
changelog.md x postpro_cal_config.yml x output_ecfp_rki (1).inp x config.inp x
19 MODSTAGE_VERSION PLAN ${DSM2MODIFIER}
20 MODEC_VERSION PLAN ${DSM2MODIFIER}
21 SJR_PROCESS MULTI_STEP #SINGLE_STEP or MULTI_STEP
22
23 START_DATE 01FEB1921 #warm-up before 192110
24 QUAL_START_DATE 02FEB1921 #warm-up before 192110
25 #START_DATE 01OCT2010
26 #QUAL_START_DATE 02OCT2010
27 # START_DATE 01DEC1921 #01OCT1974 # 01DEC2014 #
28 # QUAL_START_DATE 02DEC1921 #02OCT1974 # 02DEC2014 #
29 PTM_START_DATE ${QUAL_START_DATE}
30 END_DATE 01OCT2015 #01OCT1991 #
31 #END_DATE 01OCT2014
32 START_TIME 0000
33 END_TIME 0000
```

Note: The pre-processor needed to be run with a longer time period; that is why we are changing the dates now.

Setting up and running DSM2

alternative study: change starting and ending dates



1. open the config.inp file

2. Comment/uncomment
START_DATE, QUAL_START_DATE,
END_DATE to create a four year run, 2010-2014

```
changelog.md x postpro_cal_config.yml x output_ecfp_rki (1).inp x config.inp x
19 MODSTAGE_VERSION PLAN_${DSM2MODIFIER}
20 MODEC_VERSION PLAN_${DSM2MODIFIER}
21 SJR_PROCESS MULTI_STEP #SINGLE_STEP or MULTI_STEP
22
23 START_DATE 01FEB1921 #warm-up before 192110
24 QUAL_START_DATE 02FEB1921 #warm-up before 192110
25 #START_DATE 01OCT2010
26 #QUAL_START_DATE 02OCT2010
27 # START_DATE 01DEC1921 #01OCT1974 # 01DEC2014 #
28 # QUAL_START_DATE 02DEC1921 #02OCT1974 # 02DEC2014 #
29 PTM_START_DATE ${QUAL_START_DATE}
30 END_DATE 01OCT2015 #01OCT1991 #
31 #END_DATE 01OCT2014
32 START_TIME 0000
33 END_TIME 0000
```

Note: The pre-processor needed to be run with a longer time period; that is why we are changing the dates now.

Setting up and running DSM2

baseline study: running DSM2

- For each scenario,
 - Run the studies
 - dsm2_batch.bat

Starting the run

Run complete

```
Command Prompt
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>DSM2_batch.bat
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>..\..\bin\hydro.exe hydro.inp
Read and processed text substitution (ENVVARS), reading all data from text
Read text into buffers
H= 6.1 14478
```

Normal program end.

```
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>REM ....\bin\qual.exe qual_VOL_FP.inp
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>_
```


Setting up and running DSM2

alternative study: running DSM2

- For each scenario,
 - Run the studies
 - dsm2_batch.bat

Starting the run

Run complete

```
Select Command Prompt - DSM2_batch.bat

D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>DSM2_batch.bat

D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>..\..\bin\hydro.exe hydro.inp
Read and processed text substitution (ENVVARS), reading all data from text
Read text into buffers
No of layers=      11846
Prioritized buffer

Number of records:      3888
File Size:  48431.0  Kbytes
Percent Inactive:      0.0

-----
Normal program end.
-----

D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\alternative>
```

Setting up and running DSM2

Running DSM2

- For each scenario,
 - Run the studies
 - dsm2_batch.bat

Use chat for
questions

10:00
**10-minute
break**

Starting the run

run complete

```
Command Prompt
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>DSM2_batch.bat
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>..\..\bin\hydro.exe hydro.inp
Read and processed text substitution (ENVVARS), reading all data from text
Read text into buffers
H= 6.1 14478
```

Normal program end.

```
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>REM ....\bin\qual.exe qual_VOL_FP.inp
D:\DSM2_Planning_2023\delta\DSM2_v822plan\studies_planning\baseline>_
```

Download DSM2 Output, 4 years

- To download DSM2 outputs rather than running DSM2:
 - <https://data.cnra.ca.gov/dataset/dsm2-example-planning-study-output>

Dates in config.inp files

- Pre-processor should be run for 100 years
- DSM2 simulations for this class should be run for 4 years
- Input notebook can be run for 100 years
- Output notebooks can only be run for 4 years

Questions?

Please enter questions into the chat



Brad Tom (Bradley.Tom@water.ca.gov)

Extra slides

Running the DSM2 Pre-processor

Preprocessor errors: can't create DSS catalog files

"Cannot Create New Catalog..."

"Catalog is empty"

```
at vista.set.GroupProxy.getNumberOfDataReferences(GroupProxy.java:77)
at vista.set.Group.find(Group.java:325)
at sun.reflect.NativeMethodAccessorImpl.invoke0(Native Method)
at sun.reflect.NativeMethodAccessorImpl.invoke(NativeMethodAccessorImpl.java:62)
at sun.reflect.DelegatingMethodAccessorImpl.invoke(DelegatingMethodAccessorImpl.java:43)
at java.lang.reflect.Method.invoke(Method.java:498)
```

```
java.lang.IllegalArgumentException: java.lang.IllegalArgumentException: Catalog is empty ?
```

```
read DSM2 15-MIN output file: timeseries/2021ex.dss
postprocess pathnames:
```


```
**** ERROR - ZCAT: Catalog file Currently in use;
Cannot Create New Catalog at this Time.
```

```
/DWR/RSAC054/STAGE/01DEC1920 - 01OCT2015/15MIN/HARMONIC_NGVD_20230413/
/DWR/RSAC054/STAGE/01JAN1921 - 01SEP2015/15MIN/PLAN_DETREND_NAVD_20230413/
/FILL+CHAN/RSAC054/EC/01JAN1921 - 01SEP2015/15MIN/PLAN_2021EX/
all process done
```

```
D:\DSM2 Planning 2023\delta\DSM2 v822plan\studies planning\baseline>
```



Running the DSM2 Pre-processor

Fixing preprocessor errors



Name	Date modified	Type	Size
CALSIM	10/20/2023 9:13 AM	File folder	
2040alt.dsc	10/20/2023 9:13 AM	DSC File	276 KB
2040alt.dsd	10/20/2023 9:13 AM	DSD File	23 KB
2040alt.dsk	10/20/2023 9:13 AM	DSK File	1 KB
2040alt.dss	10/20/2023 9:13 AM	DSS File	31,608 KB

Delete all preprocessor output files




Name	Date modified	Type	Size
calsim_2040alt.dsc	10/20/2023 9:13 AM	DSC File	1 KB
calsim_2040alt.dsd	10/20/2023 9:13 AM	DSD File	0 KB
calsim_2040alt.dss	10/12/2023 6:51 AM	DSS File	400,133 KB

Delete bad catalog files

Setting up and running DSM2

Fixing preprocessor errors

1. Double click CalSim output file to open in HEC-DSSVue. This will create the catalog file.



2. Re-run the preprocessor

Box & Whisker Plot

